

21

**AIR
CONDITIONING**

LIST OF EFFECTIVE PAGES

CHAPTER	PAGE	DATE	CHAPTER	PAGE	DATE
■ 21-LEP (BA)	1	SEP 04		7	AUG 01
	2	AUG 01		8	AUG 01
21-TC (BA)	1	AUG 01	21-40-01 (BA)	201	AUG 01
	2	AUG 01		202	AUG 01
	3	AUG 01		203	AUG 01
	4	AUG 01		204	AUG 01
21-00-00 (BA)	1	AUG 01	21-40-02 (BA)	201	AUG 01
	2	AUG 01		202	AUG 01
	3	AUG 01		203	AUG 01
	4	AUG 01		204	AUG 01
21-00-00 (BA)	201	AUG 01	21-40-02 (BM)	201	AUG 01
	202	AUG 01		202	AUG 01
21-20-00 (BA)	1	AUG 01		203	AUG 01
	2	AUG 01		204	AUG 01
	3	AUG 01			
	4	AUG 01			
	5	AUG 01			
	6	AUG 01			
21-20-00 (BM)	1	AUG 01			
	2	AUG 01			
	■ 3	SEP 04			
	4	AUG 01			
	5	AUG 01			
	6	AUG 01			
21-40-00 (BA)	1	AUG 01			
	2	AUG 01			
	3	AUG 01			
	4	AUG 01			
	5	AUG 01			
	6	AUG 01			
21-40-00 (BM)	1	AUG 01			
	2	AUG 01			
	■ 3	SEP 04			
	4	AUG 01			
	5	AUG 01			
	6	AUG 01			

AAAA

Validity : S / N 1 - 9999

21-LEP (BA)

Page 1
SEP 04

PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SUBJECT	CHAPTER	PAGE	VALIDITY
AIR CONDITIONING	21-00-00 (BA)	1	1 - 9999
DESCRIPTION AND OPERATION		1	
1. GENERAL		1	
AIR CONDITIONING	21-00-00 (BA)	201	1 - 9999
MAINTENANCE PRACTICES		201	
1. SERVICING - AIR CONDITIONING		201	
A. Tools and consumable materials		201	
B. Air regulation system maintenance procedure		201	
DISTRIBUTION	21-20-00 (BA)	1	1 - 584
DESCRIPTION AND OPERATION		1	
1. GENERAL		1	
2. LOCATION		1	
3. DESCRIPTION		1	
A. Air intakes		1	
B. Distribution hoses and air outlets		2	
C. Radio ventilation (if installed)		2	
D. B13 radio fan (option)		2	
E. B17 cabin blower (option)		2	
DISTRIBUTION	21-20-00 (BM)	1	585 - 9999
DESCRIPTION AND OPERATION		1	
1. GENERAL		1	
2. LOCATION		1	
3. DESCRIPTION		1	
A. Air intakes		1	
B. Distribution hoses and air outlets		2	
C. Radio ventilation		2	
D. B13 radio fan (option)		2	
E. B17 cabin blower (option)		2	
HEATING	21-40-00 (BA)	1	1 - 584
DESCRIPTION AND OPERATION		1	
1. GENERAL		1	
2. LOCATION		1	
3. DESCRIPTION		1	
A. Heat exchanger		1	
B. Cabin air mixer		1	
C. Control box		1	
D. Distribution hoses and diffusers		2	

AAAA

Validity : S / N 1 - 9999

21-TC (BA)

Page 1
AUG 01

SUBJECT	CHAPTER	PAGE	VALIDITY
HEATING (Cont'd)	21-40-00 (BA)		
4. OPERATION		2	
A. Air regulation		2	
B. Control box		2	
HEATING	21-40-00 (BM)	1	585 - 9999
DESCRIPTION AND OPERATION		1	
1. GENERAL		1	
2. LOCATION		1	
3. DESCRIPTION		1	
A. Heat exchanger		1	
B. Cabin air mixer		1	
C. Demisting box		1	
D. Control box		2	
E. Distribution hoses and diffusers		2	
4. OPERATION		2	
A. Air regulation		2	
B. Control box		2	
HEAT EXCHANGER	21-40-01 (BA)	201	1 - 9999
MAINTENANCE PRACTICES		201	
1. SERVICING		201	
2. REMOVAL / INSTALLATION - HEAT EXCHANGER		201	
A. Tools and consumable materials		201	
B. Removal of the heat exchanger		201	
C. Installation of the heat exchanger		201	
3. ADJUSTMENT / TEST		201	
4. INSPECTION / CHECK		201	
5. CLEANING / PAINTING		201	
6. REPAIR - HEAT EXCHANGER		203	
A. Tools and consumable materials		203	
B. Heat exchanger repair		203	
CABIN AIR MIXER	21-40-02 (BA)	201	1 - 584
MAINTENANCE PRACTICES		201	
1. SERVICING		201	
2. REMOVAL / INSTALLATION - CABIN AIR MIXER		201	
A. Tools and consumable materials		201	
B. Removal of the cabin air mixer		201	
C. Installation of the cabin air mixer		201	

SUBJECT	CHAPTER	PAGE	VALIDITY
CABIN AIR MIXER	21-40-02 (BM)	201	585 - 9999
MAINTENANCE PRACTICES		201	
1. SERVICING		201	
2. REMOVAL / INSTALLATION - CABIN AIR MIXER		201	
A. Tools and consumable materials		201	
B. Removal of the cabin air mixer		201	
C. Installation of the cabin air mixer		201	

PAGE INTENTIONALLY LEFT BLANK

AIR CONDITIONING


DESCRIPTION AND OPERATION

1. GENERAL (Figures 1, 1A and 1B)

The air conditioning system consists of the sub-systems which allow intake, regulation and temperature control of the volume of air which enters the cabin.


The system consists of :

- distribution - refer to 21-20-00,
- heating - refer to 21-40-00.




Légende
Key

- ← ◻ Air froid
Cold air
- ← ◼ Air chaud
Hot air
- ← ◻◻ Air régulé
Regulated air



Air conditioning - Description and operation
Figure 1 - S/N 1 - 584


1421000AACDVZ4001




Légende

Key

- ◀ ◻ Air froid
Cold air
- ◀ ◼ Air chaud
Hot air
- ◀ ◐ Air régulé
Regulated air




Boîtier de commande air cabine
Cabin air control box



Air conditioning - Description and operation
Figure 1A - S / N 585 - 764, 766 - 878, 2000 - 9999



14210000AACDVZ4101

ADAA
Validity : S / N 1 - 9999



Légende
Key

- ◁ ◻ Air froid
Cold air
- ◀ ◼ Air chaud
Hot air
- ⬆ ◻ Air régulé
Regulated air



Boîtier de commande air cabine
Cabin air control box

Air conditioning - Description and operation
Figure 1B - S / N 765, 879 - 1999

14210000AACDVZ4201

AIR CONDITIONING

MAINTENANCE PRACTICES

1. SERVICING - AIR CONDITIONING

A. Tools and consumable materials

- Oil (TB 03-900)
- Clean lintfree cloths

B. Air regulation system maintenance procedure

NOTE 1 : The air regulation system is very simple and requires neither servicing nor adjustment.

NOTE 2 : In case of a "rough point" in the controls, simply lubricate sheathed controls and hinges with oil for satisfactory operation.

- 1) Check condition of the cabin air mixer located on the firewall.
- 2) Through baggage compartment bottom door 242, check the blower (if installed) for correct operation by means of the switch. Check the blower air intake for clogging and condition of attachments.
- 3) Check connection between fire cut-off flap and clapper located under cabin air mixer distribution box inlet.
- 4) Inspect the hoses for condition, replace if necessary.

NOTE : If new hose(s) is (are) installed, no traces of release grease (silicone) must remain inside the hose(s). Any traces must be removed with a clean lintfree cloth.

PAGE INTENTIONALLY LEFT BLANK

**DISTRIBUTION
DESCRIPTION AND OPERATION**

1. GENERAL

The distribution system allows intake and distribution of the air tapped from the atmosphere.

The system consists of :

- the air intakes,
- the distribution hoses and air outlets,
- the radio ventilation (if installed),
- the B13 radio fan (option),
- the B17 cabin blower (option).

It also uses the control box - refer to 21-40-00.

2. LOCATION

COMPONENT	QTY	AREA	ACCESS DOOR	REFERENCE
Air intakes	4	130 / 210 / 310	/	21-20-00
Distribution hoses and air outlets	/	100 / 200	131 / 211L / 211R	21-20-00
Radio ventilation (if installed)	1	250	211L	21-20-00
B13 radio fan (option)	1	250	211L / 251L	21-20-00
B17 cabin blower (option)	1	220	242	21-20-00

3. DESCRIPTION

A. Air intakes (Figures 1, 2, 3 and 3A)

The air intake, which supplies the cabin air mixer through the heat exchanger, is located on the lower cowling, on the L.H. side under the propeller spinner dome.

The NACA air intakes, located on the sides of the fuselage between the firewall and frame C1, supply fresh air to the pilot and front passenger air outlets, the radio rack and the cabin air mixer :

- the L.H. NACA air intake supplies the L.H. air outlet and the radio rack,
- the R.H. NACA air intake supplies the R.H. air outlet and the cabin air mixer.

The rear air intake, located at the root of the vertical stabilizer, supplies fresh air to both rear air outlets located on the upper duct.

As an option, a little window can be installed on the access doors to improve ventilation for the pilot and the front passenger, as well as a movable scoop on the rear transparent panels for the rear passengers.

AAAA

Validity : S / N 1 - 584

B. Distribution hoses and air outlets (Figures 1 and 2)

Distribution is ensured by flexible, reinforced hoses.

The air outlets enable each passenger to adjust and direct the desired air flow for his / her own comfort.

C. Radio ventilation (if installed) (Figures 1 and 2)

The air, at outside temperature, coming from the L.H. NACA air intake, supplies the diffuser secured to the L.H. side of the radio rack.

D. B13 radio fan (option) (Figure 1)

In order to improve the cooling of the radio rack equipment, a fan can be installed to accelerate the air circulation in the central pedestal console.

The air, at outside temperature, coming from the L.H. NACA air intake, circulates through the fan to the diffuser secured to the L.H. side of the radio rack.

The fan is secured to a support secured to the firewall, on cabin side.

An S129 thermostatic contact starts the fan as soon as the temperature reaches 113°F (45°C).


The fan is electrically supplied by "BUS 3" bar and protected by a circuit breaker located in PL1 circuit breaker panel.

E. B17 cabin blower (option) (Figures 1, 3 and 3A)

A blower, secured to the rear face of frame C6 and tapping outside air at the root of the vertical stabilizer, accelerates the cool air flow to the rear passengers. The blower ON/OFF switch is located on the overhead panel, forward of the air outlets.

The blower is electrically supplied by "BUS 2" bar and protected by "CB111" circuit breaker located in PL1 circuit breaker panel.

- 1 - Radio ventilation (if installed)
- 2 - L.H. front air outlet
- 3 - L.H. NACA air intake
- 4 - Front air intake
- 5 - B13 radio fan (option)
- 6 - R.H. NACA air intake
- 7 - R.H. front air outlet
- 8 - Rear air outlets
- 9 - B17 cabin blower (option)
- 10 - Rear air intake





14214000AACAVZ4000

Distribution - Description and operation
Figure 1

AAAA
Validity : S / N 1 - 584


- 1 - Radio ventilation (if installed)
- 2 - R.H. NACA air intake
- 3 - Front air outlets
- 4 - L.H. NACA air intake




Distribution - Air intakes, front air outlets and radio ventilation
Figure 2

14214006AAADVZ4000

AAAA
Validity : S / N 1 - 584




- 1 - B17 cabin blower switch
- 2 - Rear air outlets
- 3 - Duct in cabin
- 4 - B17 cabin blower
- 5 - Duct in rear fuselage
- 6 - Rear air intake





I4214006AAAAGW Z14200

Distribution - B17 cabin blower (option)
Figure 3 - S/N 1 - 399, 480 - 584

AAAA
Validity : S / N 1 - 584



- 1 - B17 cabin blower switch
- 2 - Rear air outlets
- 3 - Door control
- 4 - Duct in cabin
- 5 - B17 cabin blower
- 6 - Duct in rear fuselage
- 7 - Rear air intake



Distribution - B17 cabin blower (option)
Figure 3A - S/N 400 - 479

14214006AAAAGWZ4000

AAAA
Validity : S / N 1 - 584

DISTRIBUTION

DESCRIPTION AND OPERATION

1. GENERAL

The distribution system allows intake and distribution of the air tapped from the atmosphere.

The system consists of :

- the air intakes,
- the distribution hoses and air outlets,
- the radio ventilation,
- the B13 radio fan (option),

S / N 585 - 764, 766 - 878, 2000 - 9999

- the B17 cabin blower (option).

S / N 585 - 9999

It also uses the control box - refer to 21-40-00.

2. LOCATION

COMPONENT	QTY	AREA	ACCESS DOOR	REFERENCE
Air intakes	4	130 / 210 / 310	/	21-20-00
Distribution hoses and air outlets	/	100 / 200	131 / 211L / 211R	21-20-00
Radio ventilation	1	250	211L	21-20-00
B13 radio fan (option)	1	250	211L / 251L	21-20-00
B17 cabin blower (option)	1	220	242	21-20-00

3. DESCRIPTION

A. Air intakes (Figures 1, 2, 3 and 3A)

The air intake, which supplies the cabin air mixer and the demisting system through the heat exchanger, is located on the lower cowling, on the L.H. side under the propeller spinner dome.

The NACA air intakes, located on the sides of the fuselage between the firewall and frame C1, supply fresh air to the pilot and front passenger air outlets, the radio rack and the cabin air mixer :

- the L.H. NACA air intake supplies the L.H. and R.H. air outlets,
- the R.H. NACA air intake supplies the radio rack and the cabin air mixer.

S / N 585 - 764, 766 - 878, 2000 - 9999

The rear air intake, located at the root of the vertical stabilizer, supplies fresh air to both rear air outlets located on the upper duct.

ABAB

Validity : S / N 585 - 9999

S / N 585 - 9999

As an option, a little window can be installed on the access doors to improve ventilation for the pilot and the front passenger, as well as a movable scoop on the rear transparent panels for the rear passengers.

B. Distribution hoses and air outlets (Figures 1 and 2)

Distribution is ensured by flexible, reinforced hoses.

The air outlets enable each passenger to adjust and direct the desired air flow for his / her own comfort.

C. Radio ventilation (Figures 1 and 2)

The air, at outside temperature, coming from the R.H. NACA air intake, supplies the diffuser secured to the L.H. side of the radio rack.

D. B13 radio fan (option) (Figure 1)

In order to improve the cooling of the radio rack equipment, a fan can be installed to accelerate the air circulation in the central pedestal console.

In the first version of the option, the air, at outside temperature, coming from the R.H. NACA air intake, circulates through the fan to the diffuser secured to the L.H. side of the radio rack.

In the latest version, the ambient air is sucked by the fan which supplies the diffuser secured to the L.H. side of the radio rack.

Pre-MOD. 151

The fan is secured to a support secured to the firewall, on cabin side, or to the central pedestal console.

If installed, an S129 thermostatic contact starts the fan as soon as the temperature reaches 113°F (45°C).

Post-MOD. 151

The fan is secured to the central pedestal console. It operates as soon as the aircraft is energized.

14-Volt aircraft

The fan is electrically supplied by "BUS 3" bar and protected by a circuit breaker located in PL1 circuit breaker panel.

28-Volt aircraft

The fan is electrically supplied by "BUS 3" bar and protected by a fuse located in PL3 fuse panel.


E. B17 cabin blower (option) (Figures 1, 3 and 3A)

S / N 585 - 764, 766 - 878, 2000 - 9999

A blower, secured to the rear face of frame C6 and tapping outside air at the root of the vertical stabilizer, accelerates the cool air flow to the rear passengers. The blower ON/OFF switch is located on the overhead panel, forward of the air outlets.

The blower is electrically supplied by "BUS 2" bar and protected by "CB111" circuit breaker located in PL1 circuit breaker panel.

- 1 - L.H. front air outlet
- 2 - L.H. NACA air intake
- 3 - Front air intake
- 4 - B13 radio fan (option)
- 5 - Radio ventilation
- 6 - R.H. NACA air intake
- 7 - R.H. front air outlet
- 8 - Rear air outlets (if installed)
- 9 - B17 cabin blower (option)
- 10 - Rear air intake (if installed)



I4214000AAA1FYZ4001




Distribution - Description and operation
Figure 1

ABAB
Validity : S / N 585 - 9999

21-20-00 (BM)


Page 3
SEP 04

- 1 - L.H. NACA air intake
- 2 - Radio ventilation
- 3 - R.H. NACA air intake
- 4 - Front air outlets




14214006AAAAYZ4100

Distribution - Air intakes, front air outlets and radio ventilation
Figure 2




- 1 - B17 cabin blower switch
- 2 - Rear air outlets
- 3 - Duct in cabin
- 4 - B17 cabin blower
- 5 - Duct in rear fuselage
- 6 - Rear air intake




14214006AAAAGWZ14100

Distribution - B17 cabin blower (option)
Figure 3 - S / N 585 - 764, 766 - 878

ABAB
Validity : S / N 585 - 9999



- 1 - B17 cabin blower switch
- 2 - Rear air outlets
- 3 - Duct in cabin
- 4 - B17 cabin blower
- 5 - Duct in rear fuselage
- 6 - Rear air intake



Distribution - B17 cabin blower (option)
Figure 3A - S/N 2000 - 9999

14214006AAAGWZ4201

ABAB
Validity : S / N 585 - 9999

HEATING

DESCRIPTION AND OPERATION

1. GENERAL

Heating allows air regulation using the air systems from the heat exchanger and the fresh air intakes.

Temperature is controlled by the cold air / hot air ratio.

The heating system consists of :

- the heat exchanger,
- the cabin air mixer,
- the control box,
- the distribution hoses and the diffusers.

2. LOCATION

COMPONENT	QTY	AREA	ACCESS DOOR	REFERENCE
Heat exchanger	1	100	131	21-40-01
Cabin air mixer	1	100	131	21-40-02
Control box	1	230	254R	21-40-00
Distribution hoses and diffusers	/	100 / 200	131 / 211 / 235 / 236	21-40-00

3. DESCRIPTION

A. Heat exchanger (Figure 2)

The heat exchanger, installed on the exhaust pipe, heats the air coming from the air intake located on the left, under the propeller spinner dome.

B. Cabin air mixer (Figure 3)

The cabin air mixer mixes the hot air coming from the heat exchanger with the cold air coming from the R.H. NACA air intake.

Hot air / cold air adjustment is ensured, for hot air, by a fire cut-off shutter integrated into the cabin air mixer, and, for cold air, by the R.H. NACA air intake shutter.

Both shutters are controlled from the cabin via a control panel located on the R.H. side of the instrument panel strip.

The cabin air mixer is located aft of the firewall, at front passenger feet level.

C. Control box (Figures 3 and 4)

The control box is equipped with three knobs which make it possible to adjust the flow and temperature of the air entering the cabin.

The knobs control the opening of the different shutters via sheathed control cables.

S / N 1 - 274

The control box, installed in vertical position, is located on the R.H. instrument panel strip.

S / N 275 - 584

The control box, installed in horizontal position, is located on the R.H. instrument panel strip.

D. Distribution hoses and diffusers (Figures 1 and 3)

Regulated air distribution is ensured by flexible, reinforced hoses.

For the demisting function, a diffuser is installed at the bottom of the windshield and supplied by a hose connected to the cabin air mixer.

For the heating function, a diffuser (supplied by a hose) is installed between the rear passengers, at floor level. A deflector is integrated into the cabin air mixer for the front passenger feet, and a hose is directed towards the pilot feet. Both hoses are connected to the cabin air mixer.

4. OPERATION

A. Air regulation (Figure 3)

The cabin air mixer is supplied with hot air coming from the exchanger and with cold air coming from the R.H. NACA air intake.

S / N 1 - 274

Regulation is obtained by moving the R.H. knob (hot air) and the central knob (cold air).

The air mixed in the cabin air mixer is distributed in the cabin to the pilot feet and to the front and rear passengers feet.

The diffused air flow can be adjusted using the L.H. knob which controls a shutter inside the cabin air mixer.

S / N 275 - 584

Regulation is obtained by moving the upper knob (hot air) and the central knob (cold air).

The air mixed in the cabin air mixer is distributed in the cabin to the pilot feet and to the front and rear passengers feet.

The diffused air flow can be adjusted using the lower knob which controls a shutter inside the cabin air mixer.

B. Control box (Figures 3 and 4)

Hot air flow knob (A) controls the hot air flow coming from the cabin air mixer.

Cold air flow knob (B) controls the cold air flow coming from the R.H. NACA air intake.


S / N 1 - 274

Regulated air flow knob (C) controls the regulated air flow to the front and rear passengers (knob in lower position) and to the windshield (knob in upper position).

S / N 275 - 584

Regulated air flow knob (C) controls the regulated air flow to the front and rear passengers (knob in R.H. position) and to the windshield (knob in L.H. position).


- 1 - Cabin air mixer
- 2 - Pilot diffuser (feet)
- 3 - Heat exchanger
- 4 - Windshield demisting diffuser
- 5 - Control box
- 6 - Rear passengers diffuser (feet)




14214000AACAVZ4200

Heating - Description and operation
Figure 1

AFAC
Validity : S / N 1 - 584




- 1 - Clamp
- 2 - Hose
- 3 - Heat exchanger
- 4 - Hose
- 5 - Exhaust pipe (S / N 375 - 584)
- 6 - Exhaust pipe (S / N 1 - 374)
- 7 - Front box



14780000AAKUZ24200

Heating - Heat exchanger
Figure 2

AFAC
Validity : S / N 1 - 584




- 1 - Windshield demisting diffuser
- 2 - R.H. NACA air intake
- 3 - Control box
- 4 - Front passenger deflector (feet)
- 5 - Pilot diffuser (feet)
- 6 - Rear passengers diffuser (feet)
- 7 - Cabin air mixer

I4214004AAAEEVZ14000

Air regulation - Description and operation
Figure 3

AFAC
Validity : S / N 1 - 584



14214000AACCVZ14100

Heating - Control box
Figure 4

HEATING

DESCRIPTION AND OPERATION

1. GENERAL

Heating allows air regulation using the air systems from the heat exchanger and the fresh air intakes.

Temperature is controlled by the cold air / hot air ratio.

The heating system consists of :

- the heat exchanger,
- the cabin air mixer,
- the demisting box,
- the control box,
- the distribution hoses and the diffusers.

2. LOCATION

COMPONENT	QTY	AREA	ACCESS DOOR	REFERENCE
Heat exchanger	1	100	131	21-40-01
Cabin air mixer	1	100	131	21-40-02
Demisting box	1	250	211L / 211R	21-40-00
Control box	1	230	254R	21-40-00
Distribution hoses and diffusers	/	100 / 200	131 / 211 / 218 / 219 / 235 / 236	21-40-00

3. DESCRIPTION

A. Heat exchanger (Figure 2)

The heat exchanger, installed on the exhaust pipe, heats the air coming from the air intake located on the left, under the propeller spinner dome.

B. Cabin air mixer (Figure 5)

The cabin air mixer mixes the hot air coming from the heat exchanger with the cold air coming from the R.H. NACA air intake.

Hot air / cold air adjustment is ensured by a fire cut-off shutter controlled from the cabin via the control box located on the R.H. side of the instrument panel strip.

The cabin air mixer is located aft of the firewall, at front passenger feet level.

C. Demisting box (Figure 3)

The demisting box can be shut off by a fire cut-off shutter and allows hot air distribution onto the windshield via two diffusers.

This box is supplied with hot air via a hose connected to the heat exchanger.

The air flow is adjusted using the "DEMISTING" knob on the control box.

The demisting box is located at the top, on the rear face of the firewall.

D. Control box (Figure 4)

The control box is equipped with three knobs ("DEMISTING", "CABIN TEMPERATURE" and "CABIN AIR FLOW") which make it possible to adjust the flow and temperature of the air entering the cabin.

The knobs control the opening of the different shutters via sheathed control cables.

The control box is located on the R.H. instrument panel strip.

E. Distribution hoses and diffusers (Figure 1)

Regulated air distribution is ensured by flexible, reinforced hoses.

Diffusers are installed between the rear passengers, at floor level, and behind the rear bench, at head level. A deflector is secured to the cabin air mixer outlet for the front passenger feet, and a hose is directed towards the pilot feet.

4. OPERATION

A. Air regulation (Figure 5)

The cabin air mixer is supplied with hot air coming from the heat exchanger and with cold air coming from the R.H. NACA air intake.

Regulation is obtained by moving the "CABIN TEMPERATURE" knob which simultaneously controls the cabin air mixer and the R.H. NACA air intake.

The air mixed in the cabin air mixer is distributed in the cabin to the pilot feet, the front and rear passengers feet and to the upper section of the rear bench backrest.

The diffused air flow can be adjusted using the "CABIN AIR FLOW" knob which controls a shutter at the cabin air mixer outlet, in the distribution box.


B. Control box (Figures 4 and 5)

"CABIN TEMPERATURE" knob (A) controls through **a1** the hot air intake coming from hot air intake box (1), and through **a2** the cold air intake coming from R.H. NACA air intake (3) to cabin air mixer (2).

"DEMISTING" knob (B) controls through **b** the hot air intake coming from demisting box (10) to the windshield diffusers.

"CABIN AIR FLOW" knob (C) controls through **c** the quantity of air sent to the diffusers and the deflector.

- 1 - Cabin air mixer
- 2 - Heat exchanger
- 3 - Demisting box
- 4 - Control box
- 5 - Rear passengers diffuser (head)
- 6 - Rear passengers diffuser (feet)




I4214000AAAFYZ14001

Heating - Description and operation
Figure 1

ADAB
Validity : S / N 585 - 9999


21-40-00 (BM)

Page 3
SEP 04




Heating - Heat exchanger
Figure 2

1478000AAAABVZ14000



- 1 - Demisting box
- 2 - R.H. windshield diffuser
- 3 - L.H. windshield diffuser




14214003AAACVZ4000


Heating - Demisting box
Figure 3

ADAB
Validity : S / N 585 - 9999

14214000AACCVZ14200



Heating - Control box
Figure 4



- 1 - Hot air intake box
- 2 - Cabin air mixer
- 3 - R.H. NACA air intake
- 4 - Control box
- 5 - Rear passengers diffuser (feet)
- 6 - Rear passengers diffuser (head)
- 7 - Pilot diffuser (feet)
- 8 - Distribution box
- 9 - Front passenger deflector (feet)
- 10 - Demisting box

Air regulation - Description and operation
Figure 5

I4214000AAA4WZ4001

ADAB
Validity : S / N 585 - 9999

PAGE INTENTIONALLY LEFT BLANK

HEAT EXCHANGER

MAINTENANCE PRACTICES

1. SERVICING

None

2. REMOVAL / INSTALLATION - HEAT EXCHANGER (Figure 201)

A. Tools and consumable materials

- Stainless steel lockwire dia. 0.032 in (0.8 mm)

B. Removal of the heat exchanger

WARNING : PRIOR TO ANY OPERATION, ENSURE THAT THE ENGINE, EXHAUST PIPE AND MANIFOLDS ARE COLD. IF NOT, TAKE NECESSARY PRECAUTIONS TO AVOID SEVERE BURNS.

NOTE : Heat exchanger (2), Detail B, is a variant of heat exchanger (2), Detail A.

- 1) Remove the engine cowlings - refer to 71-10-01.
- 2) Remove the exhaust assembly - refer to 78-00-00.
- 3) On a table or a workbench, cut the lockwire then remove clamps (1).
- 4) Remove bolts (4), retain washers (3) - see Detail A.
- 5) Remove heat exchanger (2) from exhaust pipe (5).

C. Installation of the heat exchanger

- 1) Inspect the heat exchanger for condition. Replace any defective part.
- 2) Position heat exchanger (2) on exhaust pipe (5).
- 3) Install and tighten clamps (1).
- 4) Install bolts (4) and washers (3) - see Detail A.
- 5) Lockwire clamp (1) screws.
- 6) Install the exhaust assembly - refer to 78-00-00.
- 7) Make sure all the tools and materials are removed and the work area is clean and free from debris.
- 8) Install the engine cowlings - refer to 71-10-01.

3. ADJUSTMENT / TEST

None



4. INSPECTION / CHECK

None

5. CLEANING / PAINTING

None

- 1 - Clamp
- 2 - Heat exchanger
- 3 - Washer
- 4 - Bolt
- 5 - Exhaust pipe



14780000AAKUZ14101

Heat exchanger - Removal / Installation
Figure 201

6. REPAIR - HEAT EXCHANGER (Figure 202)

A. Tools and consumable materials

- Abrasive disc [thickness 0.06 in (1.5 mm)]

B. Heat exchanger repair

Two forms of damage should be considered :

Case No. 1 : inner surface deformed but not cracked.

Case No. 2 : inner surface deformed and cracked.


1) Case No. 1 repair

- a) Straighten out the inner surface.
- b) Using an abrasive disc, cut two diametrically opposite grooves, 0.06 in (1.5 mm) wide, in the middle of the heat exchanger on the inner surface. The grooves must have a rounded end with a 0.03 in (0.75 mm) radius and stop at 0.02 in (0.5 mm) from the outer surface, without damaging the inner surface on the outer surface, which may cause crack initiation.


2) Case No. 2 repair

- a) Straighten out the inner surface.
- b) Using an abrasive disc, confirm the crack(s) by cutting one or several grooves 0.06 in (1.5 mm) wide. The latter should be identical to those in case No. 1.

NOTE : If cracks are too numerous or excessive in size, the heat exchanger must be discarded.



Cas N° 2
Case Nr 2



Heat exchanger - Repair
Figure 202

14214000AACBVZ4000

CABIN AIR MIXER

MAINTENANCE PRACTICES

1. SERVICING

None

2. REMOVAL / INSTALLATION - CABIN AIR MIXER (Figure 201)

A. Tools and consumable materials

- Clean lintfree cloths
- Oil (TB 03-900)

B. Removal of the cabin air mixer

- 1) Remove the engine cowlings - refer to 71-10-01.
- 2) Remove the R.H. instrument panel (if installed).
- 3) Remove the closing plate of the R.H. panel.
- 4) Remove the attachments of cables (5) and (7) on control box (6).
- 5) Disconnect cables (5) and (7) from control box (6).
- 6) Remove protector (8) from cable (7).
- 7) Disconnect, on cabin air mixer (9) side, regulated air distribution hoses (2), (11) and (10) of windshield diffuser (1), rear bench diffuser (12) and pilot seat. Retain clamps (13).
- 8) Disconnect, on cabin air mixer (9) side, hose (3) of R.H. NACA air intake (4). Retain clamp (13).
- 9) Remove the 3 upper attachment bolts (16), the 4 side attachment bolts (19) on cabin side. Retain washers (21), discard nuts (22).
- 10) Hold cabin air mixer (9). Remove both upper bolts (17). Retain thickness washers (14) and washers (21). Discard nuts (22).
- 11) Disengage the box equipped with shutter (20) and cables (5) and (7). Discard seal (15).

C. Installation of the cabin air mixer

- 1) Before installation, inspect the hoses for condition. Replace if necessary.

NOTE : If new hose(s) is (are) installed, no traces of release grease (silicone) must remain inside the hose(s). Any traces must be removed with a clean lintfree cloth.

CAUTION : DO NOT FORGET THICKNESS WASHERS (14) BETWEEN CABIN AIR MIXER (9) AND FIREWALL (18). MAKE SURE SHUTTER (20) IS CORRECTLY POSITIONED.

- 2) Position cabin air mixer (9) with new seal (15) on firewall (18). Secure with 2 upper bolts (17), thickness washers (14), washers (21) and new nuts (22).
- 3) Complete the assembly with 3 upper attachment bolts (16), 4 side attachment bolts (19), washers (21) and new nuts (22), on cabin side.
- 4) Coat cables (5) and (7) with oil (TB 03-900).
- 5) Reconnect cables (5) and (7). Maneuver control box (6) levers several times and check cabin air mixer (9) flaps for correct travel.



ABAB

Validity : S / N 1 - 584

- 6) Connect, on cabin air mixer (9) side, hose (3) of R.H. NACA air intake (4). Install clamp (13).
- 7) Connect, on cabin air mixer (9) side, regulated air distribution hoses (2), (11) and (10) of windshield diffuser (1), rear bench diffuser (12) and pilot seat with clamps (13).
- 8) Install protector (8) on cable (7).
- 9) Install cables (5) and (7) attachments on control box (6).
- 10) Install the closing plate of the R.H. panel.
- 11) Make sure all the tools and materials are removed and the work area is clean and free from debris.
- 12) Install the R.H. instrument panel (if installed).
- 13) Check the R.H. instrument panel equipment once installed.
- 14) Check for leaks during run-up.
- 15) Install the engine cowlings - refer to 71-10-01.

1 - Diffuser	12 - Diffuser
2 - Hose	13 - Clamp
3 - Hose	14 - Thickness washer
4 - R.H. NACA air intake	15 - Seal
5 - Cable	16 - Bolt
6 - Control box	17 - Bolt
7 - Cable	18 - Firewall
8 - Protector	19 - Bolt
9 - Cabin air mixer	20 - Shutter
10 - Hose	21 - Washer
11 - Hose	22 - Nut

Cabin air mixer - Removal / Installation
Key to Figure 201



Cabin air mixer - Removal / Installation
Figure 201

14214003AABVZ4000

PAGE INTENTIONALLY LEFT BLANK

CABIN AIR MIXER

MAINTENANCE PRACTICES

1. SERVICING

None

2. REMOVAL / INSTALLATION - CABIN AIR MIXER (Figure 201)

A. Tools and consumable materials

- Sealant (TB 09-904)
- Oil (TB 03-900)
- Blanking caps and plugs
- Clean lintfree cloths

B. Removal of the cabin air mixer

- 1) Remove the engine cowlings - refer to 71-10-01.
- 2) Disconnect hoses (14) and (13) on distribution box (10) side. Retain clamps (15) and (12) and blank off.
- 3) Disconnect hose (1) on cabin air mixer (3) side, retain clamp (2) and blank off.
- 4) Remove the cabin air mixer by unscrewing the 12 attachment bolts (4) from the firewall and the 5 attachment bolts (16) from the cabin air mixer and the distribution box on the central pedestal console. Retain washers (5) and (17) and discard nuts (6) and (18).
- 5) Retain shim (8), plate (7), airflow shutter (19) and deflector (9).
- 6) Disconnect cable (11) (if necessary) from distribution box (10).
- 7) Clean the excess sealant (TB 09-904) from the firewall. The sealant is used to seal the cabin air mixer.

C. Installation of the cabin air mixer

- 1) Inspect the hoses for condition. Replace when necessary.


NOTE : If new hose(s) is (are) installed, no traces of release grease (silicone) must remain inside the hose(s). Any traces must be removed with a clean lintfree cloth.

- 2) Coat the contact surface of cabin air mixer (3) on the firewall with sealant (TB 09-904).
- 3) Position cabin air mixer (3).
- 4) Secure the cabin air mixer to the firewall using the 12 bolts (4), washers (5) and new nuts (6).
- 5) Position plate (7), airflow shutter (19), shim (8), deflector (9) and distribution box (10).
- 6) Coat cable (11) of distribution box (10) with oil (TB 03-900) and connect it to airflow shutter (19).
- 7) Secure distribution box (10) to the central pedestal console with the 5 bolts (16), washers (17) and new nuts (18).
- 8) Connect hose (1) to cabin air mixer (3) and secure with clamp (2).
- 9) Connect hoses (13) and (14) to distribution box (10) and secure with clamps (12) and (15).
- 10) Ensure that air conditioning controls move freely.


AAAA

Validity : S / N 585 - 9999

- 11) Make sure all the tools and materials are removed and the work area is clean and free from debris.
- 12) Install the engine cowlings - refer to 71-10-01.
- 13) Check for leaks during run-up.



- | | |
|-----------------------|----------------------|
| 1 - Hose | 11 - Cable |
| 2 - Clamp | 12 - Clamp |
| 3 - Cabin air mixer | 13 - Hose |
| 4 - Bolt | 14 - Hose |
| 5 - Washer | 15 - Clamp |
| 6 - Nut | 16 - Bolt |
| 7 - Plate | 17 - Washer |
| 8 - Shim | 18 - Nut |
| 9 - Deflector | 19 - Airflow shutter |
| 10 - Distribution box | |



14214000AAAAAWZ14100

Cabin air mixer - Removal / Installation
Figure 201

AAAA
Validity : S / N 585 - 9999

PAGE INTENTIONALLY LEFT BLANK