

CHAPTER

91

)

)

)

BOEING 707

MAINTENANCE MANUAL

PAGE	DATE	PAGE	DATE	PAGE	DATE	PAGE	DATE
CHAPTER 91 TAB							
EFFECTIVE PAGES							
SEE LAST PAGE OF LIST							
FOR NUMBER OF PAGES							
CONTENTS 91							
1	JUL 17/72						
2	BLANK						
91- 2- 0							
1	MAR 15/59						
2	MAR 15/59						

* = REVISED, ADDED OR DELETED PAGE F = FOLDCUT PAGE

CHAPTER 91 EFFECTIVE PAGES
PAGE 1
LAST PAGE

BOEING *707* *Intercontinental* 
MAINTENANCE MANUAL

CHAPTER 91

CHARTS

TABLE OF CONTENTS

<u>Subject</u>	<u>Subject No.</u>
TUBE AND HOSE IDENTIFICATION.	91-2-0

ALPHABETICAL INDEX

<u>Subject</u>	<u>Subject No.</u>	<u>Page No.</u>
COLOR CODING IDENTIFICATION CHART	91-2-0	2
TUBE AND HOSE IDENTIFICATION General	91-2-0	1

SAB REV 17 JUL. 1972

2
Dec 15/65
+



TUBE AND HOSE IDENTIFICATION

1. General

- A. The coding bands completely encircle the tube or hose.
- B. One band is located at each end of line segments longer than 24 inches.
- C. One band is located at one end of line segments shorter than 24 inches.
- D. Where a line segment passes through more than one compartment or bulkhead, additional bands are applied so that at least one band is visible in each compartment or on each side of the bulkhead.
- E. Identifying bands are located within 4 inches of the end of the tube, wherever practical.
- F. Bands do not interfere with tubing sleeves, hose connections, or bonding.
- G. Bands are not applied to lines which will be immersed in fuel tanks.
- H. When warning bands are required, one band is placed adjacent to each system color band.
- I. Coding bands on insulated ducts are applied over the insulation.

BOEING *Intercontinental* 
MAINTENANCE MANUAL

