

BOEING

707

**ILLUSTRATED TOOL
AND EQUIPMENT LIST**

DOCUMENT D6-1684

PUBLISHED BY THE BOEING COMMERCIAL AIRPLANE COMPANY • SEATTLE, WASHINGTON U.S.A.

BOEING 
COMMERCIAL JET
ILLUSTRATED TOOL AND
EQUIPMENT LIST

TO: ALL HOLDERS OF THE 707 ILLUSTRATED TOOL AND EQUIPMENT LIST, BOEING DOCUMENT
D6-1684

REVISION NO. 53, DATED JUNE 20/82

FILING INSTRUCTIONS

The Illustrated Tool and Equipment List is furnished either as a printed manual or on microfilm. This revision obsoletes all previous microfilm copies; affected microfilm cartridges are reissued with all obsolete pages deleted and all updated pages added. For printed manuals, refer to the List of Effective Pages (LEP) for the page numbers and latest date of issue of all pages within the manual.

HIGHLIGHTS

Pages which have been added, deleted or revised are outlined below together with the highlights or revision. Remove and insert the affected pages as listed and enter Revision No. 53, dated Jun 20/82, to the Record of Revision Sheet.

Chapter/Section
and Page No.

Description of Change

LICENSE AGREEMENT

<u>1</u>	Changed part numbers
<u>12-00</u> 3	Added 'NOTE'
<u>27-20</u> 3	Added 'NOTE'
<u>27-20</u>	Added new test set
<u>27-40</u> 11	Changed 'NOTE'
<u>52-00</u> 1	Added new tool no.
<u>71-00</u> 10	Changed part no., 'Usage' and 'Description'
<u>71-20</u> 2	Changed part no., added reference callouts to 'Illustration'

Jun 20/82

Transmittal Sheet
Page 1 of 1



REVISION RECORD

All revisions to this manual will be accompanied by a transmittal sheet bearing the revision number. Enter in the form below the revision number in numerical order, the date filed, and the initials of the person filing.

Revision No.	Date Filed	By	Revision No.	Date Filed	By	Revision No.	Date Filed	By

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

LIST OF EFFECTIVE PAGES					
* Indicates pages revised, added or deleted in latest revision					
F Indicates foldout pages - print one side only					
PAGE	DATE	PAGE	DATE	PAGE	DATE
TITLE PAGE					
		07-00		20-00 (Cont)	
REVISION RECORD		1	Jun 20/79	4	Sep 20/71
		2	BLANK	5	Sep 20/71
LIST OF EFFECTIVE PAGES		3	Apr 15/68	6	Sep 20/71
* 1	Jun 20/82	4	Dec 20/74	7	Sep 20/71
* 2	Jun 20/82	5	Dec 20/76	8	Sep 20/71
* 3	Jun 20/82	6	Apr 15/68	9	Sep 15/66
* 4	Jun 20/82	7	Dec 20/78	10	Sep 20/71
* 5	Jun 20/82	8	Dec 20/79	11	Dec 15/66
* 6	Jun 20/82			12	Jun 20/79
		08-00		13	Mar 20/73
CONTENTS		1	Apr 15/68	14	Jun 20/79
1	Dec 20/80	2	BLANK	15	Jun 20/77
2	Dec 20/80			16	Jun 20/79
3	Jun 20/80	09-00		17	Dec 20/79
4	Dec 20/79	1	Sep 20/71	18	Dec 20/80
* 5	Jun 20/82	2	Apr 15/67	19	Jun 20/80
6	Dec 20/79			20	Sep 20/71
7	Jun 20/79	10-00		21	Dec 20/79
8	Jun 20/80	1	Jul 15/67	22	Jun 20/73
9	Jun 20/79	2	Jul 15/68	23	Dec 20/77
* 10	Jun 20/82	3	Dec 20/73	24	Jun 20/73
11	Jun 20/81	4	Jun 20/81	25	Jun 20/73
12	Jun 20/79	5	Dec 20/80	26	Jun 20/73
13	Dec 20/79	6	BLANK	27	Jun 20/78
14	Dec 20/80			28	Dec 20/73
15	Jun 20/79	12-00		29	Dec 20/73
16	BLANK	1	Jun 20/74	30	Dec 20/73
LICENSE AGREEMENT		2	Dec 20/73	31	Dec 20/73
* 1	Jun 20/82	* 3	Jun 20/82	32	Jun 20/74
2	BLANK	4	BLANK	33	Jun 20/77
		12-20		34	BLANK
		1	Dec 20/80	21-00	
INTRODUCTION TAB		2	Jun 20/79	1	Jun 20/79
				2	Dec 20/73
INTRODUCTION		20-00		3	Dec 20/74
1	Jun 20/81	1	Sep 20/71	4	BLANK
2	Jun 20/80	2	Sep 20/71		
3	Jun 20/80	3	Sep 20/71		
4	Jun 20/80				

BOEING
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

LIST OF EFFECTIVE PAGES

* Indicates pages revised, added or deleted in latest revision

F Indicates foldout pages - print one side only

PAGE	DATE	PAGE	DATE	PAGE	DATE
21-20		24-10		27-00 (Cont)	
1	Sep 20/71	1	BLANK	6	Jun 20/74
2	BLANK	2	Jun 20/80	7	Jun 20/74
3	Sep 20/71	3	Jun 20/79	8	Jun 20/74
4	Sep 20/71	4	Jun 20/80	9	Jun 20/74
5	Mar 20/73			10	Jun 20/74
6	Jun 20/79	24-20			
7	Sep 20/71	1	Dec 20/78	27-10	
8	Sep 20/71	2	Sep 20/71	1	Sep 20/71
9	Jun 20/78	3	Jun 20/80	2	Jun 20/79
10	Sep 20/71	4	BLANK	3	Jul 15/68
11	Apr 15/68			4	Jun 20/79
12	BLANK	24-40		5	Dec 20/78
		1	Dec 20/76	6	Dec 20/78
21-50		2	Jun 20/76	7	Dec 20/78
1	Sep 20/71			8	Dec 20/78
2	BLANK	25-00		9	Dec 20/78
		1	Jun 20/74	10	Jun 20/79
22-00		2	Jun 20/74	11	Mar 20/73
1	Dec 20/73			12	Dec 20/78
2	BLANK	25-20		13	Dec 20/78
		1	BLANK	14	Dec 20/78
22-20		2	Mar 20/73		
1	BLANK			27-20	
2	Dec 20/75	25-50		1	Jun 20/79
3	Jun 20/74	1	Jun 20/73	2	Dec 20/79
4	Jun 20/81	2	Dec 15/66	* 3	Jun 20/82
5	Jun 20/74	3	Dec 20/78	4	Dec 20/74
6	BLANK	4	BLANK	5	Sep 20/71
				6	Sep 20/71
22-30		26-10		7	Sep 20/71
1	Sep 20/71	1	Jun 20/75	8	Sep 20/71
2	BLANK	2	BLANK	9	Apr 15/68
				10	Dec 20/79
23-10		27-00		11	Jun 20/73
1	BLANK	1	Jun 20/79	* 12	Jun 20/82
2	Jun 20/74	2	Jun 20/79		
		3	Jun 20/79	27-30	
24-00		4	Apr 15/68	1	Apr 15/68
1	Dec 20/78	5	Apr 15/68	2	BLANK
2	BLANK				

BOEING
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

LIST OF EFFECTIVE PAGES					
* Indicates pages revised, added or deleted in latest revision					
F Indicates foldout pages - print one side only					
PAGE	DATE	PAGE	DATE	PAGE	DATE
27-40		27-50 (Cont)		28-10 (Cont)	
1	Sep 20/71	16	Dec 20/78	7	Dec 20/76
2	Sep 20/71	17	Jan 15/68	8	Sep 20/71
3	Sep 20/71	18	Dec 20/78	9	Jun 20/79
4	Sep 20/71	19	Dec 20/73	10	Jun 20/78
5	Jun 20/77	20	Dec 20/78	11	Dec 20/76
6	Jun 20/73	21	Dec 20/73	12	Dec 20/78
7	Mar 20/73	22	BLANK		
8	Apr 15/67			28-30	
9	Jun 20/73	27-60		1	Jan 15/68
10	Jan 15/68	1	BLANK	2	BLANK
* 11	Jun 20/82	2	Jul 15/69		
12	Jun 20/79	3	Jun 20/79	28-40	
13	Dec 20/74	4	Jun 20/74	1	Jun 20/81
14	BLANK	5	Dec 20/74	2	BLANK
15	Dec 20/74	6	BLANK	3	Dec 20/73
16	BLANK			4	Apr 15/68
17	Jul 15/67	27-70		5	Jun 20/73
18	Jun 20/79	1	Jun 20/73	6	BLANK
19	BLANK	2	Sep 20/71		
20	Jun 20/74			29-00	
21	Jul 15/67	27-80		1	Sep 20/71
22	Dec 20/78	1	Dec 20/77	2	Jun 20/73
		2	Dec 20/77	3	BLANK
27-50		3	Dec 20/77	4	Jan 15/68
1	Sep 20/71	4	BLANK	5	Jun 20/75
2	Jun 20/73	28-00		6	Jun 20/75
3	Sep 20/71	1	Jun 20/73	7	Jun 20/75
4	Jun 20/75	2	Jun 20/79	8	BLANK
5	Jun 20/79	3	Dec 20/73		
6	Dec 20/80	4	Jun 20/74	29-10	
7	Sep 20/71			1	Mar 20/73
8	Mar 20/73	28-10		2	Apr 15/68
9	Sep 20/71	1	Sep 20/71	3	Jun 20/75
10	Apr 15/67	2	BLANK	4	BLANK
11	Dec 20/78	3	Dec 20/80		
12	Dec 20/78	4	Sep 20/71	30-40	
13	Dec 20/78	5	Sep 20/71	1	Jun 20/79
14	Dec 20/78	6	Jun 20/79	2	BLANK
15	Dec 20/78				
				32-00	
				1	Jun 20/74
				2	BLANK

BOEING
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

LIST OF EFFECTIVE PAGES

* Indicates pages revised, added or deleted in latest revision

F Indicates foldout pages - print one side only

PAGE	DATE	PAGE	DATE	PAGE	DATE
32-10		32-20 (Cont)		33-40	
1	Sep 20/71	3	Jun 20/79	1	Apr 15/67
2	Dec 20/78	4	Sep 20/71	2	Apr 15/67
3	Oct 15/67	5	Sep 20/71		
4	Oct 15/67	6	BLANK	34-00	
5	Sep 20/71	7	Jul 15/69	1	Jun 20/77
6	Sep 20/71	8	Dec 20/77	2	Dec 20/78
7	Jul 15/67	9	Jun 20/81	3	Dec 20/73
8	Jul 15/67	10	BLANK	4	Mar 20/73
9	Jul 15/67			5	Dec 20/74
10	Dec 20/73	32-30		6	Mar 20/73
11	Sep 20/71	1	Dec 20/78		
12	Mar 20/73	2	Dec 20/78	34-10	
13	Sep 20/71	3	Dec 20/78	1	Jun 20/74
14	Sep 20/71	4	Dec 20/78	2	Jun 20/77
15	Dec 20/80	5	Dec 20/78		
16	Dec 20/80	6	Dec 20/78	34-20	
17	Apr 15/68	7	Sep 20/71	1	Dec 20/80
18	Apr 15/68	8	Dec 20/78	2	Jun 15/66
19	BLANK	9	Sep 20/71	3	Dec 20/80
20	Dec 20/80	10	Dec 20/78	4	Dec 20/80
21	Jun 20/73	11	Dec 20/78	5	Dec 20/80
22	Dec 20/71	12	Dec 20/78	6	Dec 20/80
23	Jan 15/68	13	Dec 20/78		
24	Dec 20/78	14	BLANK	35-20	
25	BLANK			1	Jun 20/80
26	Jun 20/72	32-40		2	BLANK
27	Apr 15/68	1	BLANK		
28	Dec 20/71	2	Dec 20/77	49-00	
29	Dec 20/71	3	Dec 20/77	1	Jun 20/74
30	Dec 20/71	4	Jul 15/68	2	Jun 20/75
31	Dec 20/78	5	Jun 20/79	3	Dec 20/78
32	Jun 20/81	6	BLANK	4	BLANK
33	Dec 20/71				
34	Jun 20/77	32-50		51-00	
35	Jun 20/77	1	Apr 15/68	1	Dec 20/77
36	BLANK	2	Apr 15/68	2	BLANK
		3	Sep 20/71		
		4	Sep 20/71		
32-20					
1	Jul 15/67				
2	BLANK				

BOEING
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

LIST OF EFFECTIVE PAGES					
* Indicates pages revised, added or deleted in latest revision					
F Indicates foldout pages - print one side only					
PAGE	DATE	PAGE	DATE	PAGE	DATE
51-10		53-00		55-30	
1	Jun 20/80	1	Jun 20/74	1	Dec 20/77
2	Jun 20/80	2	Dec 20/73	2	Dec 20/80
3	Jun 20/80			3	Jun 20/77
4	Jun 20/80	53-30		4	Dec 20/73
5	Jun 20/80	1	Jun 20/79	5	Jun 20/77
6	Jun 20/80	2	BLANK	6	Dec 20/77
7	Jun 20/79				
8	Jun 20/80	53-50		55-40	
		1	Apr 15/68	1	Sep 20/71
52-00		2	BLANK	2	Mar 20/73
* 1	Jun 20/82	54-10		55-50	
2	Jun 20/79	1	Jun 20/80	1	BLANK
3	Dec 20/78	2	BLANK	2	Dec 20/76
4	BLANK				
52-10		55-00		57-00	
1	Sep 20/71	1	Mar 20/73	1	Dec 20/76
2	Mar 20/73	2	BLANK	2	Dec 20/74
3	Mar 20/73				
4	Sep 20/71	55-10		57-10	
5	Jun 20/79	1	Dec 20/80	1	Dec 20/76
6	Jun 20/77	2	Dec 20/80	2	Sep 20/71
7	Jun 20/77	3	Jun 20/73	3	Dec 20/76
8	Jun 20/79	4	Jun 20/78	4	Dec 20/76
9	Dec 20/79	5	Sep 20/71		
10	Dec 20/79	6	Sep 20/71	57-40	
11	Dec 20/80	7	Sep 20/71	1	Jun 20/78
12	Jun 20/81	8	Jun 20/78	2	Jun 20/78
		9	Sep 15/66	3	Dec 20/76
52-20		10	Jun 20/78	4	Jun 20/78
1	Apr 15/68	11	Sep 15/66		
2	BLANK	12	BLANK	57-50	
		13	BLANK	1	Jun 20/77
52-30		14	Dec 20/73	2	Dec 20/78
1	Jun 20/74	55-20		3	Dec 20/78
2	Jul 15/69	1	Dec 20/77	4	Dec 20/78
3	Jun 20/74	2	Apr 15/68		
4	Dec 20/78	3	Dec 20/77	71-00	
5	Dec 20/78	4	BLANK	1	Jun 20/78
6	BLANK			2	BLANK

BOEING
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

LIST OF EFFECTIVE PAGES

* Indicates pages revised, added or deleted in latest revision

F Indicates foldout pages - print one side only

PAGE	DATE	PAGE	DATE	PAGE	DATE
71-00 (Cont)		73-20		78-30 (Cont)	
3	Dec 20/77	1	Sep 20/71	8	Sep 20/71
4	Sep 20/71	2	Jun 15/66	9	Sep 20/71
5	Sep 20/71	3	BLANK	10	Dec 20/73
6	Mar 20/73	4	Jun 20/74	11	Sep 20/71
7	Oct 20/69			12	Mar 20/73
8	Jan 20/70	75-30		13	Dec 20/74
9	Sep 20/71	1	Apr 15/68	14	Dec 20/74
* 10	Jun 20/82	2	BLANK	15	Dec 20/74
11	Jun 15/66	76-00		16	Jun 20/79
12	BLANK	1	Jun 20/79	17	Jul 15/68
13	Dec 20/79	2	Jun 15/66	18	Dec 20/73
14	Jun 20/73	3	Jun 20/75	19	Dec 20/74
15	Jul 15/67	4	BLANK	20	Dec 20/74
16	Jul 15/67	76-10		21	Dec 20/75
17	Jul 15/68	1	Sep 20/71	22	BLANK
18	Jul 15/68	2	Dec 20/73	79-20	
19	Dec 20/75	3	Jul 15/68	1	Sep 20/71
20	Dec 20/77	4	Jun 20/76	2	Sep 20/71
21	Dec 20/75	5	Apr 15/68	3	Sep 20/71
22	Dec 20/75	6	Apr 15/68	4	Sep 20/71
23	Jul 15/69	7	Dec 20/73	NUMERICAL INDEX	
24	Jun 20/78	8	BLANK	TAB	
25	Jul 15/69	77-10		NUMERICAL INDEX	
26	Jul 15/69	1	Jun 20/81	* 1	Jun 20/82
27	Dec 20/78	2	BLANK	2	Jun 20/78
28	Dec 20/78	78-20		3	Dec 20/80
71-10		1	Sep 20/71	4	Dec 20/80
1	Dec 20/78	2	Sep 20/71	5	Dec 20/80
2	Dec 20/78	78-30		6	Dec 20/79
3	Dec 20/78	1	Sep 20/71	* 7	Jun 20/82
4	BLANK	2	Mar 20/73	8	Dec 20/80
71-20		3	Sep 20/71	9	Jun 20/80
1	Dec 20/77	4	Sep 20/71	10	Dec 20/80
* 2	Jun 20/82	5	Jul 15/67	11	Dec 20/80
3	Jun 20/79	6	Jul 15/67	* 12	Jun 20/82
4	Dec 20/77	7	Sep 20/71	13	Dec 20/80
72-00				14	Jun 20/80
1	Sep 20/71			15	Dec 20/80
2	Sep 20/71			16	Jun 20/80

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
07-	LIFTING AND SHORING		
	Airplane Recovery Tethering Fittings		
	Outboard O-Ring	F70315-1	1
	Aircraft Jacking Adapter Assembly	F71139	3
	Aircraft Jacking Adapter Assembly	F71138-500, -501	4
	Aircraft Jacking Adapter Assembly	F70009,-1	5
	Aircraft Jacking Adapter Assembly	F71156	6
	Aircraft Jacking Adapter Kit.	F80060-1, -6	7
	Fuselage Lifting Sling Assembly	F70244-17	8
08-	LEVELING AND WEIGHING		
08-00	Airplane Attitude Gage Assembly	F70043	1
09-	TOWING AND TAXIING		
09-00	Airplane Towing and Steering Bar Assembly	F71136-500, -503, -505	1
10-	PARKING AND MOORING		
10-00	External Rudder Lock.	F70118	1
	Plug, Shield and Cover Kit.	F70063-500, -502	2
	Pitot Tube Cover Assembly	F70060	3
	Louvered Surge Bleed Port Cover	F70296-1	4
	Engine Surge Bleed Port Plug	F71224	5
12-	SERVICING		
12-00	Tire Inflation Tool	F70199-1	1
	Strut Inflation Tool.	F70200-1	2
	Valve Core Removal, Tire Deflation Tool	F70294-1	3
12-20	Lubrication Fitting Assembly.	SEL2-5201	1
	Entry, Cargo, Service and Galley Door Camshaft Bearings Lubrication Set.	F72942-1	2
20-	STANDARD PRACTICES		
20-00	Teflon Seal Installation Tool Kit	F72789-19	1
	Bearing Press Fitting Mandrels.	ST918A,B,C,D	2
	Bearing Point Staking Tool.	ST925	3
	Bearing Roller Staking Tool	ST926A	4
	Bearing Ball Point Staking Tool	ST931,A	5
	Bearing Removal Tool.	ST927	6
	Bearing Installation Support.	ST919,MP	7
	Bearing Roller Staking Tool	ST932	8
	Bearing Ring Housing and Shaft Type Swaging Tool.	ST933,-100	10
	NAS1368 Grommet Installation Tool	ST1065C	11
	Access Panel Screw Removal Tool	SE20-0002	13

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
20-00	STANDARD PRACTICES (Cont)		
	AN Standard Type Wrench Spanner	F72959-1 thru -12	12
	Bearing Roller Swaging Tool	ST926E	14
	Bearing Removal Tool.	ST927C	15
	Bearing Staking Ball Point Yoke	ST931B-375-812	16
	Roller Swaging Tool	ST932C	17
	Shrink Fit Bushing Installation Mandrel . . .	F70321-1 thru -40	18
	Roller Swage Kit.	F80113-1,-34,-37	19
	Roller Swage Assembly	F80117-1	20
	Surface Resistivity Measurement, Probe. . . .	ST895A-3	21
	Flareless Fittings Gage	ST841-A	22
	Bearing Removal Tool.	ST927B	23
	Rigging Pins Kit.	F70207-1	24
	Control Cable Clamp	ST2207B	25
	Control Cable Turnbuckle Clamp.	ST2715	26
	Rod End Bearing Socket Wrench	F71313-13,-14, -15,-19,-20,-21	27
	Rod End Bearing Wrench.	ST2580-103-1, -2,-3	28
	Bearing Sleeve Roller Swaging Tool.	ST929-1A	29
	Bearing Line Staking Tool	ST929-4	30
	Bearing Housing Roller Swaging Tool	ST932B	31
	Bearing Ball Staking Tool	ST931D	32
	Bearing Housing Drive Screw Filler Flap Roller Swaging Tool	F70297-1	33
21-	AIR CONDITIONING		
21-00	Cabin Pressure Controller Connector Breakout Box Assembly.	F70211-1	1
	Outflow Valve Connector Breakout Box Assembly	F70210-1	2
	Cabin Pressure Selector Connector Breakout Box Assembly.	F70212-1	3
21-20	Turbocompressor Surge Bleed Outlet Plug Assembly	F71246	1
	Air Inlet Plug Assembly	F71452-5	3
	Turbocompressor Exhaust Plug Assembly	F70120	4
	Air Conditioning Adapter Section Wrench Assembly	F71268	5
	Air Conditioning Turbofan Exhaust Duct Plug Assembly	F70151,-7	6
	Air Conditioning Ram Air Inlet Plug Assembly.	F70081-1,-2	7
	Air Conditioning Ram Air Inlet Plug Assembly.	F71181,-500	8
	Air Conditioning Ram Air Inlet Plug Assembly.	F70146-1,-2, -11,-12	9

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
21-20 (Cont)			
	Air Compressor Inlet Plug Assembly	F70023	10
	JT3C and JT4A Engines Turbocompressor Exhaust Plug Assembly	F70056	11
21-50	Cooling Air Outlet Plug Assembly	F70041	1
22-	AUTO FLIGHT		
22-00	Servo Torque Measurement Fixture Assembly . .	F70183-500	1
22-20	Attitude Warning System Wing Test Kit	F70130-500	2
	Mach Trim System Analyzer	F71375	3
	Elevator/Rudder/Aileron Power Control Unit Test Set	F72785-1,-51, -101,-500	4
22-30	Auto Throttle Clutch Test Jig	F72808-1	1
23-	COMMUNICATIONS		
23-10	HF Communications System Test Set and Adapter Assembly	F71420,-200	2
24-	ELECTRICAL POWER		
24-00	Battery Charger to Battery Adapter	F70245-1	1
24-10	Constant Speed Drive and Alternator Mounting Hoist Assembly	F70140,-500,-502, -505	
	AC Generator and Drive Mounting Adapter Assembly	F71206-500, -502,-503	3
	AC Generator and Constant Speed Drive Adapter Assembly	F72863-1,-2	4
24-20	Generator and Heat Exchanger Exhaust Plug Assembly	F71399	1
	AC Generator Exhaust Plug Assembly	F71247	2
	Constant Speed Drive and A.C. Generator Adapter	F70333-1,-21	3
24-40	Ground Power Plug and Receptacle Wear Gage. Ground Power Plug and Receptacle Wear Gage Set	SE24-4001-1,-2 F70284-1	1 2
25-	EQUIPMENT/FURNISHINGS		
25-00	New Interior and Protective Cargo Panels Stowage Pallets	F70247-1	1
25-20	Interior Trim Remover Assembly	F70033	2
25-50	Cargo Loading Body Support Strut Assembly .	F70153,-500,-501	1
	Cargo Loading Threshold Adapter Set	F70174-1,-2,-3	2
	Roller Pallet Adapter	F70-252-1	3

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
26-	FIRE PROTECTION		
26-10	Fire Detection Control Unit Breakout Box. . .	F70213-1	1
27-	FLIGHT CONTROLS		
27-00	Protractor Clamp Assembly	F71292-16	1
	Protractor Stand Assembly	F71292-17	2
	Airplane Control Surfaces Protractor Assembly.	F52485-500	3
	Double Angle Gearbox Assembly Spanner Wrench.	5MIT5-97039-1	4
	Double Angle Gearbox Assembly Clamp and Wrench.	6MIT5-97039-1	5
	Stabilizer Trim Actuator Umbrella Seal Guide Assembly.	F70254-1	6
	Stabilizer Trim Actuator Housing Nut Wrench Adapter.	F70255-1	7
	Stabilizer Trim Actuator Locknut Wrench Adapter	F70256-1	8
	Stabilizer Trim Actuator Jamnut Spanner Wrench.	F70257-1	9
	Stabilizer Trim Control Rigging Tool.	F70261-1	10
27-10	Control Actuator Bearing Puller Assembly. . .	F70150	1
	Control Column Protractor Assembly.	4M1T65B80307-1	2
	Outboard Aileron Gearbox Assembly Aligning Fixture Assembly.	F71263	3
	Control Wheel Protractor Mount.	F72790	4
	Control Column Splined Wrench	F72797	5
	Control Column Holding Fixture.	TSJ5-87879-1	6
	Control Column Holding Fixture.	F70320-1	7
	20/40 External Spline Adapter	F70190-1	8
	Aileron Tab Control Pressure Unit Assembly. .	2TSJ65-74038-1	9
	Sickle Protractors and Mounts	As tabulated	10
	Control Wheel Straightedge.	SE27-0001	11
	Aileron Control Snubber Cycling Jig	TSJ5-88763-7	12
	Control Mechanism Test Fixture Assembly . . .	F72846-1	13
27-20	Rudder PCU Forward Attach Bolt Removal and Installation Equipment.	F70331-1	1
	T.E. Flaps Rigging Bar.	F70332-1	2
	"Q" Spring Ram Air Intake Gage and Adapter Assembly.	F71429,-500	3
	Vertical Tail Installation Rudder Setting Protractor and Scale.	MIT50-8703	4
	Rudder Power Control Test Jig	2TSJ65-6511	5
	Rudder Flutter Damper Assembly Test Jig . . .	TSJ65-5947-2	6
	Rudder Control Damper Assembly Test Jig . . .	TSJ65-8353	7
	"Q" Spring Assembly Holding Fixture	TSJ69-6017	8

BOEING
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
27-	FLIGHT CONTROLS (Cont)		
	Ball Bearing Screw Actuator Assembly Test		
	Jig	TSJ10-60173	9
	Rudder Pedal Force Check, Adapter	F80212-1	10
	Rudder Centering Spring Mechanism Assembly		
	Jig	AJ65-14802	11
	Ram Air Intake Q Spring Test Set.	F70337-1	12
27-30	Elevator Snubber Assembly Test Jig.	2TSJ50-1571-5	1
27-40	Bearing Retainer Nut Spanner Wrench	F70087	1
	Stabilizer Trim Actuator Socket Wrench.	F70105	2
	Stabilizer Trim Actuator Wrench Assembly.	F70109	3
	Stabilizer Trim Actuator Spring Retainer		
	Adapter Wrench Assembly	F70159	4
	16/32 Inch Spline 3/4 Inch Male Hex Adapter	F71252	5
	Pinion Gear Wrench Assembly	F71267	6
	Bearing Retainer Nut Spanner Wrench	F71289	7
	Bearing Retainer Nut Spanner Wrench	F71290-1,-2,-7	8
	Stabilizer Trim Actuator Spring Compressor.	F71291-500	9
	Stabilizer Trim Lock Assembly	F71336-501	10
	End Play Check Fixture.	F71421,-500,-501	11
	Stabilizer Trim Jackscrew Ball Nut and Screw		
	Assembly Holder Assembly.	SE27-1001	13
	Manual Stabilizer Trim Wheel		
	Torque Wrench Adapter	F70326-1	12
	Stabilizer Trim Jackscrew Ball Nut and Screw		
	Assembly Holder Assembly.	SE27-1011	15
	Stabilizer Trim Control Installation		
	Miscellaneous Tool.	MIT50-8704	17
	Stabilizer Trim Hand Wheel Torque Wrench		
	Adapter	TE65-20804	18
	Stabilizer Trim Actuator Secondary Brake		
	Gage.	SE27-4502	20
	Stabilizer Trim Actuator Assembly Jig	F70167-1	21
	Stabilizer Trim Actuator Gear Retainer		
	Wrench.	7MIT5-88439	22
27-50	Inboard Flap Drive Splined Shaft Adapter.	F70067	1
	Flap Position Transmitter Assembly Tools Kit.	F70131	2
	Pin Spanner Socket Wrench	F71207	3
	Splined Coupling Spanner Wrench	F71228,-500	4
	Fillet Flap Hinge Pins Puller Set	F70293-1	5
	Flap Straightedge Miscellaneous Tool.	2MIT65-1063-1	6
	Wing Flap Control Installation Check Fixture.	MIT50-8707-1	7
	Wing Flap Control Installation Check Fixture.	MIT50-8707-2	8
	Flap Control Valve Holding Fixture.	TSJ50-6875	9

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
27-	FLIGHT CONTROLS (Cont)		
27-50	Bolt Puller Assembly.	F70173-1	10
	Torsion Bar Outboard Cove Lip Doors		
	Clamp Set	F70319-1	11
	Torsion Bar Inboard Cove Lip Door		
	Clamp Set	F70322-1	12
	Flap Drive Adapter.	F70300-1	13
	Fillet Flap Sling	F70246-1	14
	Cove Lip Door Latch Wear Template	F70177-1, -2, -3	15
	Flap Drive Ball Screw and Nut Test Fixture.	ME10-2562	16
	Inboard and Fillet Flap Drive Power Unit		
	Manual Rotating Holder.	MIT65-20846-1	17
	Outboard Cove Lip Door Actuation		
	Installation Miscellaneous Tool	2MIT65-18940-1	18
	Cove Lip Door Spring Assembly Tool.	MIT65-18940-1	20
27-60	Spoiler Actuator Lock Assembly.	F71264-500, -501	2
	Actuator Loader Test Fixture Assembly	F71196-501	3
	Spoiler Actuator Cylinder Sleeve Adapter.	SE27-6002	4
	Cove Lip Door Spring Cartridge		
	Piston Extractor Assembly	SE27-2004	5
27-70	Rudder Snubber Retainer Holder Wrench		
	Assembly.	F71190	1
	Elevator Snubber Assembly Test Kit Assembly	F71262	2
27-80	Leading Edge Wing Flap Actuator Lock		
	Assembly.	F70064	1
	Wing Leading Edge Flaplocks Kit	F70064-503	2
	Wing Leading Edge Flaplock Assembly	F70144	3
28-	FUEL		
28-00	Sealant Tools	ST982A,B,C	1
	Sealant Cutting and Scraping Tools.	ST982H,J-4,L,L-1	2
	Hollow Bolt Fuel Leak Tracing Adapter		
	Assembly.	F70206-1	3
	Fuel System Self-Sealing Rivets Temporary		
	Repair Tool	F70230-1	4
28-10	Fuel Drain Valve Wrench Assembly.	F65834-500	1
	Auxiliary Defueling External Power Control		
	Unit.	F70316-1	3
	Boost Pump Cavity Leakage Test Plate		
	Assembly.	F71327	4
	Integral Tank Leakage Test Leakage Tracing		
	Device.	F71329	5
	Integral Tank Leakage Test Door Assembly.	F71349-2,-502	6

BOEING
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
28-	FUEL (Cont)		
28-10	Auxiliary Fuel Vent System Coverplate	SE28-1106	7
	Torque Spanner.	ST2580-302	8
	Wingtip Fuel Vent System Coverplate Assembly.	F70209-1	9
	Test Equipment Water Manometer Assembly . . .	F70208-1	10
	Auxiliary Fuel Vent System, Coverplate. . . .	F70289-1	11
	Water Manometer Test Equipment	F72951-1	12
28-30	Actuator Load Fixture Test Jig.	TSJ10-60414	1
28-40	Fuel Quantity System Adapter Assembly	F72731-81,-82	2
	Fuel Jettison Hydraulic Snubber Test Jig. . .	2TSJ50-9368-3	3
	Fuel Jettison Snubber Test Jig.	TSJ50-9368-3	4
	Fuel Dump Chute Actuator Test Harness	F70215-1	5
29-	HYDRAULIC POWER		
29-00	Flareless Tube Fitting Sleeve "Sleeve-Set" Presetting Tool	ST878D	1
	O-Ring Installation Tools	ST848	2
	Hand-Operated Tube Bender	ST850BHB	4
	MS21922 Flareless Tube Fitting Hand Presetting Tool	ST879A	5
	Hand Presetting Tools ST879A Holding Fixture.	ST879AF	7
29-10	Hydraulic Pump to Engine Attach Bolts Wrench.	SE29-1102	1
	Hydraulic Reservoir Test Jig.	TSJ50-10803	2
	Hydraulic Leakage Check Cable Assembly. . . .	F80135-10	3
30-	ICE & RAIN PROTECTION		
30-40	Window Heat Control Unit Breakout Box	F70216-1	1
32-	LANDING GEAR		
32-00	Landing Gear Axle Thread Protector.	F72880-1	1
32-10	Main Landing Gear Oleo Lock Assembly.	F70027,-502,-503	1
	MLG Axle Lock Bolt Alignment Pin.	F70314-1,-2	2
	Metering Pin Wrench Assembly.	F70053	3
	Metering Pin Wrench Assembly.	F70106	4
	9 Inch Diameter Hook Spanner Wrench	F70107	5
	Main Landing Gear Oleo Lock Assembly.	F70112,-500	6
	Main Landing Gear Lock Assembly	F71126-500,-501	7
	Main Landing Gear Door Downlock Assembly. . .	F71127	8
	Metering Pin Nut Wrench Assembly.	F70138-1,-2	9
	Main Landing Gear Oleo Lock Assembly.	F70147	10
	MLG Actuator Beam Pin Puller Assembly	F71160	11
	11 Inch Diameter Hook Spanner Wrench.	F71283	12
	Piston Head Retaining Nut Bar Wrench.	F71284	13
	MLG Inner Cylinder O-Ring Guide Assembly. . .	F71312	14

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
32-	LANDING GEAR (Cont)		
	Main Landing Gear Axle Protector.	F71355	15
	Main Landing Gear Axle Protector.	F71355-500	16
	Main Landing Gear and Trunnion Bolt Puller Kit	F72792-500,-501, -502,-503	17
	Main Landing Gear Door Actuator Test Jig. . .	F70286-1	20
	Main Landing Gear Door Lock Switch Adjusting Tool.	SE32-1001	21
	Main Landing Gear Wheel Installation Fixture.	12FME5-83045	22
	Main Landing Gear Inner Cylinder O-Ring Guide Assembly.	F70114	23
	Main Landing Gear Installation Dolly.	23TME5-83045	24
	Pivot Bolt Locknut Spanner Wrench	4AJ65-21000-1	26
	Inboard Wheels Antiskid Hub and Outboard Main Gear Doors Scuff Plate	2MIT5-86308-3127	27
	Main Landing Gear Piston Tube Socket Wrench .	2AJ69-23003	28
	Main Landing Gear Piston Tube Spanner Wrench.	AJ69-23003	29
	Main Landing Gear Piston Tube Installer . . .	4MIT65-28034	30
	Axle Lock Bolt Alignment Pin.	SE32-7003	31
	Main Gear Aft Trunnion Bushings Expander Assembly.	F70186-10	32
	Main Landing Gear Ring Assembly Seal Installation.	F71342	33
	Main Landing Gear Gland Nut Spanner Wrench. .	F72767-3	34
	Sleeve Rod and Head Ends MLG Actuator Roller Swaging Tool	F70292-1	35
32-20	Nose Landing Gear Downlock Assembly	F70008-500,-501	1
	Nose Landing Gear Downlock Assembly	F71125	3
	2.00 Inch Face Pin Spanner Wrench	F71132	4
	5.00 Inch Face Lug Spanner Wrench	F71133	5
	Nose Gear Transportation and Wheel Installation Dolly.	4PME5-83046	7
	Nose Gear Drag Brace Drill Jig Kit.	F70189-1	8
	Nose Landing Gear Oleo Lock Assembly.	F70263-1	9

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
32-30	LANDING GEAR		
	Landing Gear Selector Valve Rigging Tool. . .	MIT5-97815	1
	Landing Gear Valve Control Installation Miscellaneous Tool.	MIT50-8710-53	2
	Main Gear Emergency Release Installation Miscellaneous Tool.	3MIT50-1401	3
	Main Gear Emergency Release Installation Miscellaneous Tool.	MIT50-1401	4
	Main Landing Gear Emergency Release Installation Miscellaneous Tool	2MIT50-1401	5
	Main Gear Centering Cylinder and Snubber Assembly Test Jig	TSJ65-32023-1	6
	2.90 Inch Diameter Hook Spanner Wrench. . . .	F71172-500	7
	Lever Assembly Holding Fixture.	TSJ50-3309-2	8
	Main Landing Gear Snubber Functional Test Pin Assembly.	F71177	9
	Nose Gear Lock Actuator Jig Assembly.	F71288	10
	MLG Snubber Drill Jig Assembly.	F71279-500	11
	Nose Gear Actuator Support Jig.	TSJ50-6819-4	12
	Crowfoot Wrench, Kit (Replaces F71173, F71173-1, F71184)	F70312-1	13
32-40	Landing Gear Installation Wrench Assembly . .	26ME5-83045	2
	Skid Detector Nut MLG Torque Adapter.	F70306-1	3
	Main Gear Brake Bleed Clamp Assembly.	F70171-12	4
	Brake Installation and Removal Adapter Assembly.	F72849-1	5
32-50	3-Inch Diameter Hook Spanner Wrench	F70013	1
	Nose Gear Rigging Protractor Assembly	F70110,-18,-500	2
	1.75-4.00 Inch Diameter Hook Spanner Wrench Assembly	F71170	3
	Hydraulic Pressure Adapter Assembly	F71188-7,-8	4
33-	LIGHTS		
33-40	Landing Light Installation, LH and RH	MIT50-10373-1,-2	1
	Landing Light Installation, LH and RH	MIT65-20690-1,-2	2

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
34-	NAVIGATION		
34-00	Static Port Test Adapter Assembly	F72823-3,-4, -23,-37,-38,-40	1
	Speed Command Module Test Box	F70287-1	2
	Vertical and Direction Gyro Tilt Table Adapter Assembly.	F70194-1	3
	Vertical Gyro Extension Cable	F80139-1	4
	INS and Gyro Units Tilt Table	2TSJ60B00002	5
	Vertical Gyro Extension Cable	F80138-1	6
34-10	Speed Command Accessory Unit M4226 Test Breakout Box Assembly.	F70259-1	1
	Static Port Drill Fixture Rework Kit.	F72926-27	2
34-20	Compass Swinging Target and Bracket Kit Assembly.	F70036	1
	Compass Swing, Transit Support Target Assy. .	F70327-1	5
	Compass Swinging Target Accessory Kit Assembly.	F71187-500	3
	Compass Swinging Target Assembly.	F52269-500	4
35-20	Oxygen Mask Restraint Assembly.	F70329-1,-2,-11	1
49-	AUXILIARY POWER UNIT		
49-00	Model 707 Lower Lobe APU Adapter Standard Transportation Cart	F70249-1,-2	1
	APU Installation/Removal Hoist and Stowage Assembly.	F70193-2,-3, -20,-48	2
	APU Inlet and Exhaust Doors Test Harness. . .	F70318-1	3
51-	STRUCTURES		
51-00	Nacelle Strut Midspar Bolt Puller	F70180-1	1
51-10	Outboard Aileron Balance Test Jig Support Fitting	TSJ5-88190-1	1
	Inboard Aileron Static Balance Test Jig . . .	TSJ5-86072-1	2
	Stabilizer Tab, Elevator and Rudder Support Control Fitting Test Jig.	2ME5-87157	3
	Elevator and Rudder Balance Panels Test Jig Support Fitting	2ME5-97214	4
	Elevator and Rudder Test Jig Support Fitting.	3ME5-96190	5
	Control Surfaces Balance Jig Stand.	FME5-71799	6
	Radome Repair Eddy Current Probe Kit.	F80124-1	7
	Static Balance Equipment Control Switches . .	F70330-1,-4	8
52-	DOORS		
52-00	Door Seal Installation Tool	SE52-1002 or B52004-1	1
	Station 990 Emergency Exit Restraining Strap Assembly.	F70196-1	2
	Galley and Entry Door Torque Wrench Adapter .	ST2580-257	3

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
52-10	Door Handle Mechanism Nut Wrench Assembly . .	F70038	1
	Bearing Retainer Nut Spanner Wrench	F70085	2
	Galley and Entry Door Hinge Pin Puller Kit. .	F70086	3
	Entry and Galley Door Snubber Assemblies Test Jig.	TSJ90-10072-1	4
	Forward Entry Door Canopy Assembly.	2ME50-7945	5
	Forward Entry Door Latch Roller Setting Tool.	F80178-1	6
	Galley and Entry Door Torque Wrench	F80171-1	7
	Forward Entry Door Canopy	F70324-1	8
	Screwdriver Bit	ST1813A	9
	Safety Barrier, Entry Door.	4PRE50-7945	10
	Entry Door Hinge Fitting Line Reaming Tool. .	F70335-1	11
	Main Entry Door Assist Handle Spanner Wrench .	F70336-1	12
52-20	Escape Slide Hand Press Assembly.	F70178-1	1
52-30	Main Cargo Door Sill Protector.	F70156,-500	1
	Cargo Door Actuator Lock Assembly	F70157-500	2
	Main Cargo Door Lifting Fixture	MIT65-25326-2	3
	Cargo Door Personnel Safety Barrier	F70258-1	4
	Main Cargo Door Lifting Fixture Assembly. . .	F70250-1,-2,-4	5
53-	FUSELAGE		
53-00	Cable Insertion Tool.	F70221-8	1
	Groove Gage	F70227-1	2
53-30	Film Resistance Measuring Probe	F70328-1	1
53-50	Tail Cone Hoist Sling Assembly.	F70132	1
54-	NACELLES/PYLONS		
54-10	Nacelle Strut Installation/Removal Sling Assembly.	F70334-1	1
55-	STABILIZERS		
55-00	Bolt Kit Splice Maintenance Puller.	F70025	1
55-10	Stabilizer Support Jack Assembly.	F52238-501	1
	Stabilizer Jack screw Support Assembly. . . .	F70057-500	2
	Stabilizer Bearing Assembly Removal and Installation Kit.	F70158-500,-501, -502,-503,-504, -505,-506	3
	Horizontal Stabilizer Sling Assembly.	F71130-500,-501	4
	Horizontal Stabilizer Hinge Pin and Bearing Puller Assembly	F71135	5
	2-1/8 Inch Double Hex Socket Wrench Assembly.	F71142	6
	5.75 Inch Spanner Wrench.	F71189	7

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
55-	STABILIZERS		
55-10	Horizontal Stabilizer Sling	F70172-1	8
	Horizontal Stabilizer Sling	F70172-2	10
	Thrust Brace Attach Bolt Puller Assembly. . .	F70188-1, -2, -3	14
55-20	Elevator Hoisting Sling Assembly.	F71144-500, -501	1
	Elevator Balance Cavity Seal Installation Facility Gage	CF65-5647	2
	Elevator Sling.	F70307-1	3
55-30	Aircraft Maintenance Adapter Assembly	F70020, -500	1
	Fin Raising and Lowering A-Frame Assembly . .	F70030-500, -501	2
	Vertical Fin Support Assembly	F71140, -501	3
	Vertical Fin Rear Spar Terminal Fitting Special Wrench.	F70145-1	4
	Fin Hoisting and Folding Sling Assembly (Replaces F71131-502)	F70298-1	5
	Restraining Line Vertical Fin Adapter	F70304-1	6
55-40	Rudder Hoisting Sling Assembly.	F70059	1
	Rudder Trim Tab Protractor.	MIT50-8706	2
55-50	Horizontal Stabilizer Rear Spar Pin Removal Tool.	F70272-1	2
57-	WINGS		
57-00	Wingtip Bolt Torque Adapter	2ME5-73119	1
	Bearing Removal Tool.	F70197-1	2
57-10	External Wrenching Torque Adapter	F70016, -500	1
	Outboard Wing Panel Sling Assembly.	F71143-500	2
	Internal Wrenching Offset Adapter	F71151-12-7	3
	Torque Wrench Adapter Set	F70291-1	4
57-40	Front Bottle Pin and Bushing Puller Kit . . .	F70154, -13	1
	Aft Bottle Pin and Bushing Puller Kit	F70155, -19	2
	Outboard Wing Attach Adapter.	23MIT5-73110	3
	Outboard Wing Attach Adapter.	24MIT5-73110	3
	Fwd and Aft Wing Bottle Pin and Bushing Removal Puller Kit.	F70310-1	4
57-50	Inboard Aileron Sling (Replaces ME5-73133-1). Inboard and Outboard Flaps Installation Sling	F70301-1 F70229-301, -302, -303	1 2
	Flap Track and Spoiler Support Drill Jig Assembly.	F70179-1	4

BOEING
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
71-	POWER PLANT-GENERAL		
71-00	Fan Engine Cowl Actuator Restrictor	F70311-1	1
	Rear Mount to Overhead Rails JT3D		
	Engine Hanger	F70305-1	3
	JT4 Engine, Engine Air Intake Shield		
	Assembly.	F70065	4
	Sound Suppressor-Thrust Reverser Support		
	Assembly.	F70089	5
	JT3D Engine Exhaust Plug.	F70122-1	6
	JT3D Engine Fan Exhaust Cover	F70124-1,-2	7
	JT3D Engine Inlet Plug.	F70126	8
	JT3D Engine Handling Kit.	F70142,-500	9
	Three Engine Ferry Engine Inlet and Fan Exit	F70163-1,-2,	
	Cover	-3,-4	10
	Pt7 Pressure Engine Trim Gage	F72973-10	13
	Engine Hoisting Sling Assembly.	F70137,-500,	14
		-501	
	48 Inch Wide Rail System JT3D Engine		
	Lift Adapter Kit.	F71401	17
	J57, JT3C Engine Inlet Plug	F71430	18
	Engine Forward Hanger Mount	3MIT65-10684	19
	Engine Rear Hanger Mount.	4MIT65-10684	20
	Diaphragm Locating Tool	5MIT65-10606	21
	Cowl Ring Locator Block Tool.	6MIT65-10684	22
	Turbocompressor Locating Tool	5MIT65-10684	23
	JT3D Engine Cowl Ring Restraint Harness	MIT65-10621	24
	Strut Simulator	15ME65-10684	25
	Strut Duct Locating Tool.	2MIT65-10684	26
	Engine (JT3D) Forward Hanger Mount.	F70279-1	27
	Fan Duct Diaphragm Locating Tool.	F70280-1	28
71-10	RH Cowl Panel Buildup Tool.	ME64-8327-0	1
	LH Cowl Panel Buildup Tool.	ME64-8327-1	2
	JT3D Fan Reverser Cowl Ring Locating		
	Block Set	F70281-1	3

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
71-20	Engine Mount Bolts Thread Protector	F70266-303,-304	1
	Reversible Ratchet Wrench Assembly.	F71418,-500	2
	Modified Ratcheting Box Socket Wrench	L06-7161-2-31	
		L06-7161-2-60	3
	Engine Mount Bolts Thread Protector Sets.	F70266-300,-301	4
72-	ENGINE TURBINE/TURBOPROP		
72-00	Dummy Engine Weight	2MIT5-85616	1
	LH and RH dummy Engine Fixtures	MIT65-2447-1	2
		MIT5-85616-1	2
73-	ENGINE FUEL AND CONTROL		
73-20	Fuel Control Gage Assembly.	F70102	1
	Throttle Control Adjusting Tool	F70240-1	4
76-	ENGINE CONTROLS		
76-00	JT3D Engine Control Wrench Kit.	F71435	1
	Engine Start Lever Special Rigging Spacer	F70248-2	3
76-10	Throttle Warning Horn Protractor Assembly	F70024	1
	Reverse Thrust Lever Protractor Assembly.	F70044	2
	Throttle Rigging Lock Assembly.	F70084-1,-2,-23, -24,-27	4
	Engine Nacelle Throttle Control Miscellaneous Tool.	MIT65-2471	5
	JT3C7 Engine Throttle Control Installation Miscellaneous Tool.	4MIT65-2868	6
	Reverse Thrust Lever Protractor Assembly.	F70044-500	7
77-	ENGINE INDICATING		
77-10	Engine Test Remote Tachometer	F70303	1
78-	EXHAUST		
78-20	JT4A Engine Sound Suppressor Cover Assembly	F70111	1
	JT3C Sound Suppressor Cover Assembly.	F70026	2
78-30	Thrust Reverser Hoist Adapter	F70051	1
	Clamshell Retracting Rod Assembly	F70061	2
	Thrust Reverser Wrench Assembly	F70068	3
	Thrust Reverser Bearing Retainer.	F70071	4
	Thrust Reverser Bearing Sleeve.	F70072	5
	Thrust Reverser Bearing Sleeve.	F70073	6
	JT4A Thrust Reverser and Sound Suppressor Installation Adapter.	F70103	7
	JT3D Engine Thrust Reverser Cradle.	LF70141	8
	Clamshell Door Rod Assembly	F70165-1	9
	Clamshell Door Contour Template Assembly.	F70166-1	10

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

<u>Section</u>	<u>Title</u>	<u>Part No.</u>	<u>Page No.</u>
78-	EXHAUST		
	JT3D Engine Tailpipe and Thrust Reverser		
	Adapter Assembly.	F71403	11
	Clamshell Door Contour Template Assembly.	F72747	12
	Thrust Reverser Actuator Assembly Tool.	SE78-3005	13
	Thrust Reverser Valve Restraining Fixture	SE78-3003	14
	Forward Thrust Reverser Actuator End Cap		
	Spanner Plate	SE78-3004	15
	Protractor Forward Thrust Lever		
	Adapter Set	F72952-3	16
	Face Spanner Lug Wrench Adapter	F70175-1	17
	Pin Spanner Wrench.	ST2580-127B-5	18
	Aft Thrust Reverser Lock Actuator Ring		
	Compressor.	SE78-3010	19
	Fan Reverser Countersunk Nut Clamp.	F70195-1	20
	JT3D Fan Thrust Reverser Rigging Gauge.	F70275-1	21
79-	OIL		
79-20	Oil Cooler and Starter Exhaust Plug Assembly.	F70045	1
	Engine Oil Cooling Unit Plug Assembly	F70066	2
	Oil Cooler and Fuel Air Exhaust Plug		
	Assembly.	F70078	3
	Engine Oil Cooling Inlet Plug Assembly.	F71198	4

BOEING 
COMMERCIAL JET
 ILLUSTRATED TOOL AND
 EQUIPMENT LIST

LICENSE AGREEMENTS WITH GSE SUPPLIERS

The Boeing Company has licensing agreements with the following GSE suppliers to provide Boeing designed special tools and ground handling equipment listed in this document in accordance with Boeing provided technical data. It should be noted that some suppliers are licensed to provide all items, whereas others supply only specific items.

These agreements with suppliers are not intended to prevent airline customers from manufacturing or having manufactured for their own use all items listed in this document.

ALL GSE ITEMS - ALL MODELS

- | | |
|---|--|
| 1. P.F. Industries, Inc.
9320 15th. Ave So.
Seattle, Washington 98108 | 2. Spec Tool Co.
P.O. Box 1056
Pico Rivera, Calif. 90660 |
| 3. AGSE Corp.
3270 East 70th St.
Long Beach, California 90805 | 4. Stang Hydronics, Inc.
767 N. Main Street
Orange, California 92668 |

SELECTED ELECTRICAL-ELECTRONIC GSE

1. Farwest Special Products Inc.
 13427 S.E. 27th Place
 Bellevue, Washington 98005

<u>Model</u>	<u>Part Number</u>	<u>Model</u>	<u>Part Number</u>
707	F70131	707/727/737	F80138-1
707	F70210-1	707/727/737/747	F80139-1
707	F70211-1	707/727/737/747/757	F70328-1
707	F70212-1		
707	F70213-1		
707	F70215-1		
707	F70216-1		
707	F70259-1		
707/727/737	F70303-2		
707/727/737/747	F70316-1		
707	F71375		
707	F71420,-200		
707/727/737	F72731-81		
707/727/737	F72785-1,-51		
747	-101,-500		
707/727/737	F72973-10		
707/727/737	F80135-10		

