


<b>sabena</b> <b>B707</b>	Module: VERT STAB + FL C	A/C Reg :	Check :	
	Oper. : RT-MP LC			
	Type : MEC-INSP	Issuer : A62165	Cert.St.: 46928	<b>71F2000504</b>
Spec. : MECHANIC	Release Date: 19.12.2006		<b>Page 1 of 2</b>	


**RUDDER TAB HINGES FIT ASSY INSP**

			<b>MAINT</b>	<b>RII/INSP</b>
Execution / Start Date:				
End Date:				

Pos	Mat. Type	P/N	IDN	Description	Qty	Unit
1	FL & CH	.		BMS 3-23	0.00	

--	--	--	--	--	--	--

**RUDDER TAB HINGES FIT ASSY INSP**

<b>sabena</b> <b>B707</b>	Module: VERT STAB + FL C	A/C Reg :	Check :	
	Oper. : RT-MP LC			
	Type : MEC-INSP	Issuer : A62165	Cert.St.: 46928	71F2000504
Spec. : MECHANIC	Release Date: 19.12.2006		Page 2 of 2	

**RUDDER TAB HINGES FIT ASSY INSP**

					MAINT	RII/INSP
Nr.	Hardtime	Task	Spec.	Related Documents		
1.		E3 S	MEC	AD 94-10-06 rev 8913 MMS-328 554040 01000 rev 15/05/01 SB 707-55-3409 rev DEC 12/91		
<b>Check: C</b>						
<b>Zones: 395, 396</b>						
<b>Access:</b>						

**RUDDER TAB HINGES FITTINGS ASSY INSPECTION.**

1. a. Remove RUDDER TAB per AMM 27-17-11.
  - b. Remove hinge fittings from TAB.
2. Visual inspect hinge fittings for cracks.
3. Check bearings for free rotation.
4. Visually inspect the four attach screws & cylindrical nuts for evidence corrosion.
5. Apply corrosion inhibiting compound BMS 3-23 on hinge fittings.
6. a. Reinstall RUDDER TAB hinges.
  - b. DUPLICATE INSPECTION.
  - c. Reinstall RUDDER TAB per AMM 27-17-11.
  - d. DUPLICATE INSPECTION.