



| | | | | |
|---|--------------------------|-----------------|-----------------|---|
| sabena [®] B707 | Module: COCKPIT + WINDOW | A/C Reg : | Check : |  81K0000532 |
| | Oper. : RT-MP LC | | | |
| | Type : *OPER./FUNC. CHE | Issuer : A43710 | Cert.St.: 24828 | Page 1 of 2 |
| Spec. : ELECTRICIAN | Release Date: 16.10.2001 | | | |

EMER LIGHT F/C

| | |
|-------------------------|--|
| Execution / Start Date: | |
| End Date: | |

| MAINT | RII/INSP |
|-------|----------|
| | |

| | | | | |
|------------------------------|--------------------------|-----------------|--------------------|--|
| sabena B707 | Module: COCKPIT + WINDOW | A/C Reg : | Check : |  |
| | Oper. : RT-MP LC | | | |
| | Type : *OPER./FUNC. CHE | Issuer : A43710 | Cert.St.: 24828 | 81K0000532 |
| Spec. : ELECTRICIAN | Release Date: 16.10.2001 | | Page 2 of 2 | |

EMER LIGHT F/C

| | | | | | MAINT | RII/INSP |
|---|----------|------|-------|-----------------------------------|-------|----------|
| Nr. | Hardtime | Task | Spec. | Related Documents | | |
| 1. | | F2 | REI | MMS-328 335001 00100 rev 15/05/01 | | |
| Check: C2 | | | | | | |
| Zones: 223, 224, 226, 228, 229, 242, 248 | | | | | | |
| Access: | | | | | | |
| <p>CONDITION:</p> <ul style="list-style-type: none"> - Electrical power ON. - C/B 115V EMERGENCY EXIT LIGHTS or ESS PWR FAIL WARNING on P2 CLOSED. - C/B 28v DC EMERGENCY EXIT LIGHT CONT LH, RH on P6 CLOSED. - C/B EMERGENCY EXIT LIGHT CONTROL CENTER on P6 CLOSED. <p><u>EMERGENCY LIGHTS FUNCTIONAL CHECK.</u></p> <ol style="list-style-type: none"> 1. Set emergency light switch to OFF and check: <ul style="list-style-type: none"> - Interior exit & emergency lights OFF. - Exterior overwing lights OFF(if installed). 2. Set emergency switch to ON and check: <ul style="list-style-type: none"> - Interior & exterior lights ON. 3. Set emergency switch to ARMED and check: <ul style="list-style-type: none"> - Interior & exterior lights OFF. 4. Open 115VAC emergency exit light or ess power failure warning c/b on P2 and check: <ul style="list-style-type: none"> - Interior & exterior lights ON. 5. Set emergency switch to OFF. 6. Close c/b 115 VAC EMERGENCYEXIT LIGHTS or ESS POWER FAILURE WARNING on P2 panel and check: <ul style="list-style-type: none"> - Interior & exterior lights OFF. | | | | | | |