



sabena B707	Module: CABIN + WINDOWS	A/C Reg :	Check :	 91K0000508
	Oper. : RT-MP LC			
	Type : *OPER./FUNC. CHE	Issuer : A59513	Cert.St.: 50516	
Spec. : ELECTRICIAN	Release Date: 19.05.2010		Page 1 of 2	

PAX CAB PORT OXY BOTTLE S/O VLV F/C

Execution / Start Date:	
End Date:	

MAINT	RII/INSP

PAX CAB PORT OXY BOTTLE S/O VLV F/C

sabena B707	Module: CABIN + WINDOWS	A/C Reg :	Check :	
	Oper. : RT-MP LC			
	Type : *OPER./FUNC. CHE	Issuer : A59513	Cert.St.: 50516	91K0000508
Spec. : ELECTRICIAN	Release Date: 19.05.2010		Page 2 of 2	

PAX CAB PORT OXY BOTTLE S/O VLV F/C

					MAINT	RII/INSP	
Nr.	Hardtime	Task	Spec.	Related Documents			
1.		F1	REI	MMS-328 353001 00100 rev 15/05/01			
Check: C							
Zones: 226							
Access:							
NRC YES <input type="radio"/> NO <input type="radio"/>		IF YES, NUMBER(S):					

PAX CABIN PORTABLE OXYGEN BOTTLE SHUTOFF VALVES OPERATIONAL CHECK.

Operational check of pax cabin portable oxygen bottle shutoff valves.

PROCEDURE:

- A. Check ALL portable oxygen bottle shutoff valves by cracking them open, to assure they are not jammed in the CLOSED position.
- B. Valves should be completely closed above check is made.

NOTES: THE 7 BOTTLES ARE LOCATED IN THE OVERHEAD STOWAGE BINS.